

HENRIK TABLE LAMP

Item no.

G0001856PT 220-240V ~ 50Hz LED E27 Max 5W G45 Golf Ball Ta:30°C







Assembly Instructions

PLEASE ASSEMBLE THE PRODUCT BY THE BELOW STEPS:

- 1. Put the shade into socket,
- 2. Put ring into socket, then screw
- 3. Put LED E27 bulb into socket.

CAUTIONS: THIS ITEM HAS A "TYPE Y" CORD.

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid hazard.